

BF 225 Alarms

<u>Alarm</u>	<u>Lights</u>				<u>Condition</u>
	Oil Pressure	Overheat (Red)	MIL (Red)	Alternator (Red)	
None	ON	OFF	OFF	OFF	Normal
Continuous	OFF	OFF	OFF	OFF	Low Oil Pressure
Continuous	ON	ON	OFF	OFF	Overheat
Continuous	OFF	ON	OFF	OFF	Low oil pressure & overheat
Continuous	OFF	OFF (2)	ON	OFF	Low oil pressure & abnormal PGM-FI
Continuous	OFF	OFF	OFF	ON	Low oil pressure & abnormal alternator
Continuous	OFF	OFF	OFF	OFF	Low oil pressure & water in separator filter
Continuous	ON (1)	ON	ON	OFF	Overheat & abnormal PGM-FI
Continuous	ON	ON	OFF	ON	Overheat & abnormal alternator
Continuous	ON	ON	OFF	OFF	Overheat & water in separator filter
Long Intermittent	ON (1)	OFF (2)	ON	OFF	Abnormal PGM - FI
Long Intermittent	ON	OFF	OFF	ON	Abnormal alternator
Long Intermittent	ON (1)	OFF (2)	ON	ON	Abnormal PGM - FI & abnormal alternator
Long Intermittent	ON (1)	OFF (2)	ON	OFF	Abnormal PGM-FI & water in separator filter
Long Intermittent	ON	OFF	OFF	ON	Abnormal alternator & water in separator filter
Short Intermittent	ON	OFF	OFF	OFF	Water in separator filter

NOTE 1: Light blinks when PGM-FI detects abnormal oil pressure (high pressure side)

NOTE 2: Light blinks when the PGM-FI detects engine overheat